




PVS Sensors Inc. Phone: 1-800-988-1276
 PO Box 100 Fax: 864-638-0005
 2810 Blue Ridge Blvd Website: www.pvssensors.com
 West Union, SC 29696 Email: sales@pvssensors.com

Installation Instructions for BMA Pressure Switches

Adjusting the Set Point

(Switch is factory set at the lowest value of the adjustment range with the exception of range #2: set at 1500psi Rising)

Turn the knob clockwise to increase the set point or counter-clockwise to decrease until desired set point is reached.



	Adjustment Range (psi)	Average Differential (psi)	Proof Pressure (psi)
BMA - 1	10 - 435	Less than 10% of Actuation Point	25,000
BMA - 2	250 - 5500		25,000
BMA - 3	5000 - 7500		25,000

(For latest revisions, please visit www.pvssensors.com)

Contact	Spade (Fig 1)	Flying Leads	DIN HC/HN (Fig 2)	Integral Deutsch 2 pin (Fig 3)	M12X1 (mating connector 2 pin wire code) (Fig 4)	Integral Deutsch 3 pin (Fig 5)
Common	C	Black	Pin 1	Pin 1	Pin 3 (Black)	Pin C
N. Open	NO	Red	Pin 3	Pin 2	Pin 4 (White)	Pin A
N.Closed	NC	Green	Pin 2	Pin 2	Pin 1 (Green)	Pin B

